

Technical Data

MagicSun

Tanning Tube OH M 23/160 R

UV-Code:^{**} 160-R-117/7,2

Article No.: 45007054

Dimensions: See drawing (not to scale)
 Socket: G13 / BiPin
 Reflector: with reflector, type R (reflector angle 210 °)

Electrical Data:
 Lamp Wattage nom.: 160 W
 Lamp Voltage: 130 V
 Lamp Current: 1,5 A
 Open-circuit voltage: 230 V / 50 Hz
 Ballast: Ballast 160 LP
 Starter: OH Suncare Power 100 - 180 W
 Compensation: 18,0 µF(± 10% 250V)

Operation conditions:
 Cooling: Convection
 Burning Position: Horizontal
 Surrounding temperature: 25 °C ±1 °C

Irradiation Data:
 UVA Output: 46 W
 UVB Output: 2,3 %
 Sun erythema factor:^{*} 0,39
 Luminous colour: Standard blue
 (UVB:280-315 nm; UVA:315-400 nm)
 $E_{er \text{ total}}^*$: 117,1 mW/m² $E_{NMSC \text{ total}}^*$: 209,5 mW/m²
 $E_{er \leq 320}^*$: 92,8 mW/m² $E_{NMSC \leq 320} / E_{NMSC > 320}^*$: 7,2
 $E_{er > 320}^*$: 24,3 mW/m² E_{pi}^* : 27,2 W/m²

Lifetime:
 Standard lifetime: 1.000 h
 Reduction of UV-intensity: ≤ 20 % (315-400 nm) after 700 h
 Based on: 20 h - value

The data given are based on average data und has been determined by measurements made in the laborator under standard conditions. There could be minor deviations due to technical and/or physical reasons.

^{*} These irradiation data of a single tube have been measured in a distance of 25 cm.

^{**} Valid with 1h preageing process, 25 cm distance between tube surface and sensor, in thermal balance.

Sunbed intensity ^{*1} (315-400 nm)	UV- ^{*2} Device type	First ^{*3} tanning time	Tanning time in minutes ^{*3}			MED/h Skin type 3	UV- ^{*4} Index
			Skin type 2	Skin type 3	Skin type 4		
30 mW/cm ²	No	2 min	5 min	7 min	9 min	9	34
35 mW/cm ²	No	2 min	4 min	6 min	7 min	10	40
40 mW/cm ²	No	1 min	4 min	5 min	7 min	12	46
46 mW/cm ²	No	1 min	3 min	4 min	6 min	13	52

^{*1} UVA- Sunbed intensity, measured in heighth of the skin surface; ^{*2} Referring DIN EN 60335-2-27; ^{*3} Referring DIN 5050 Part 2; ^{*4} Referring B

Heraeus Noblelight GmbH
 Original Hanau SunCare
 Heraeusstraße 12-14
 D-63450 Hanau
 Phone: +49 6181 / 35-5092
 Fax.: +49 6181 / 35-5096
 E-Mail: suncare@heraeus.com
www.original-hanau-suncare.com

